


NOTE

This diagram is to be used with the measurement form to determine points of measurement.



STREAKER ALLOY MAST - Supplied by :-
Selden - LAMBDA Section
or
Superspars - MHR Section

STREAKER CLASS OWNERS ASSOCIATION
GUIDE TO BUILDER & MEASURERS
- SHEET No 8 (SPARS)